



The world's favourite lock since 1843

3-8 digit  
 x x x x x x x x




RESET



SET CODE      in

x x x x x x x x >

ENTER ERASE <

3-8 digit  
 x x x x x x x x



OPEN

x x x x x x x x >

ENTER ERASE <



ErrOr 1

ErrOr 2

ErrOr 3

ErrOr 4



ErrOr x1 → ErrOr x2 → ErrOr x3 → ErrOr x4

buzzer



3 min

